




## Installation of 1/4 inch line Double Spouted Undersink Faucet Kit For Melody & Athena

### Your Undersink Kit Includes:



Faucet Kit




Cold Water Tee Connector with 3/8 in. and 1/2 in. Adapter (1)



Top Spout Adapter (1)



1/4 in. X 5/16 in. 90 deg Fitting (1)



**Trim Ring:** Stays on the faucet so that it sits on the top of the Trim Ring Gasket and the counter or sink.

**Trim Ring Gasket:** Stays on the faucet for installation. This sits in between the trim ring and the counter or sink.

**Large Washer:** Will go underneath your counter or sink.

**Large Hex Nut:** Will go underneath your counter or sink and secure the faucet against the Large Washer.


## Important:

- Please follow instructions carefully as IonWays cannot accept responsibility for any consequences resulting from improper installation. If you have questions, please call AlkaViva Technical Services at 775-324-2400, Option 2.
- You will need to be able to access the Control Panel on the front of the ionizer both during and after installation in order to use all of your ionizer's functionality.
- The ionizer should be unplugged and powered off during installation.
- Teflon tape is required for Step 5 of installation; Teflon tape was provided with ionizer at time of purchase.


## Installation Instructions:

1. Drill a 1-3/8 in. hole in countertop if one does not already exist. The hole for the soap dispenser can be used in most cases.
2. Remove the **Large Hex Nut** and the **Large Washer** (see page 1 for pictures).
3. Insert all four (4) hoses in the 1-3/8 in. hole in countertop or sink.
4. Reinstall the **Large Washer** followed by the **Large Hex Nut** and thread the **Large Hex Nut** snugly against the bottom of the countertop or sink. You can use a wrench to tighten. \* Be careful to not over tighten the Large Hex Nut. This could cause damage to the faucet.
5. Wrap the threads of the **Top Spout Adapter** with Teflon Tape 2-3 Times.
6. Attach the **Top Spout Adapter** to the top of your ionizer. This will take place of the flexible stainless steel tube. The flexible tube unthreads from the top spout of the ionizer to make room for the Dark Grey Threaded Fitting.
7. Push the larger size (5/16 in.) of the **1/4 in. X 5/16 in. 90 deg Fitting** onto the Acidic Water outlet on the bottom of your ionizer and give a quick pull on the fitting to insure a good connection that will not leak.
8. Connect the hoses from the faucet assembly to the ionizer:
  - A. **RED** line: Plug into the **1/4 in. X 5/16 in. 90 deg Fitting** on the bottom side of your ionizer.
  - B. **CLEAR** line: Plug into the **Top Spout Adapter**.
  - C. **BLUE** line: Plug into the Water Tap inlet on the bottom of the water ionizer.
  - D. **GREEN** line: Plug into the water source (See Page 3).
9. Turn off the water supply on the cold water line at the existing angle stop valve under your sink.

\*Depending on your plumbing measurements, it MAY be necessary to attach the cold water adapter at this part of the installation as follows:



Adapter installed here translates to 3/8 in. fitting




Adapter installed here translates to 1/2 in. fitting

10. Unscrew the existing water line at the cold water angle stop (usually 3/8 in. stainless braided hose). Attach the female end of the **Cold Water Tee Connector with 3/8 in. and 1/2 in. Adapter** to the angle stop.  
\* Teflon is not required on these threads but we advise you to wrap 3-4 times with the Teflon Tape.
11. Attach the female end of the hose you removed to the threaded side of the **Cold Water Tee Connector with 3/8 in. and 1/2 in. Adapter.**
12. With the **GREEN** line in hand, push the line into the 1/4 in. fitting on the **Cold Water Tee Connector with 3/8 in. and 1/2 in. Adapter.**
13. Plug the ionizer into a dedicated surge protected or GFI outlet and turn the power switch on the back of the ionizer to the ON position.
14. Turn on the cold water supply at the existing angle stop valve and check for leaks. Turn the **blue** shut off valve handle on the Cold Water T Connector to the ON position by pointing the handle in the same direction as the **GREEN** line.
15. Turn on the flow control valve at the front of your ionizer.

This completes the installation of your Double Spouted Undersink Faucet.

Be sure to turn the faucet on and let it run for a few minutes to  
rinse the inside of the faucet before drinking.

\*See next page for faucet measurements.\*



**Measurements In Inches**

Size Bit for Drilling	1 3/8 - 1
Hose Length	34.00
Nut Outside Diameter Size	1.25
Nut Inside Diameter Size	1.00
Measurement A	6.00
Measurement B	9.00
Measurement C	3.00
Measurement D	5.00
Measurement E	2.50
Measurement F	1.00